

IC-27300D/A/E Frequency expansion

RX Frequency expansion

Frequency range: 118.000 – 136.99166MHz [AM]

137.000 – 174.000MHz [FM]

375.000 – 550.000MHz [FM]

#02 EUR-01	No need of Modification
#03 ITR-01	Key operation only
#04 TPE-01	Remove D321, after that, key operation
#05 USA-01	No need of Modification
#06 KOR-01	Key operation only
#09 EXP-01	No need of Modification
#10 CHN-01	No need of Modification

Key operation:

1. Turn off the radio
2. Push and hold simultaneously [MONI] and [Low], then turn on by pushing [PWR] key.

TX Frequency expansion

Frequency range: 137.000 – 174.000MHz [FM]

400.000 – 470.000MHz [FM]

#02 EUR-01	Remove D307 and D315
#03 ITR-01	Remove D307 and D315
#04 TPE-01	Remove D307 and D315
#05 USA-01	Remove D307 and D315
#06 KOR-01	Remove D307 and D315
#09 EXP-01	No need of Modification
#10 CHN-01	No need of Modification

