

# OPTIONS FOR HANDHELD TRANSCEIVERS

MODEL NAME	AC ADAPTERS			SPEAKER-MICROPHONES					
	BC-147S*2 12V/0.25A	BC-157S 12V/6.6A	BC-206SE*2 15V/0.4A	HM-138 IPX7	HM-158L/LA HM-131SC	HM-159L/ LA/SC	HM-168/LWP IPX7	HM-169 IP67	HM-170GP IP57 GPS
IC-F3262DT/DS, IC-F4262DT/DS									
IC-F3162DT/DS, IC-F4162DT/DS	✓ (Use with BC-171)	✓ (Use with BC-121N or BC-197)			✓ (Use HM-131SC)	✓ (Use HM-159SC)	✓ (Use HM-168)	✓	✓
IC-F3102D, IC-F4102D		✓ (Use with BC-197)	✓ (Use with BC-192)		✓ (Use HM-158L)	✓ (Use HM-159L)			
IC-F51V, IC-F61V	✓ (Use with BC-152N)	✓ (Use with BC-121N)		✓			✓ (Use HM-168)	✓	✓
IC-F51, IC-F61 ATEX	✓ (Use with BC-152N)	✓ (Use with BC-121N)		✓					
IC-F3032S, IC-F4032S	✓ (Use with BC-171)	✓ (Use with BC-121N or BC-197)			✓ (Use HM-158LA)	✓ (Use HM-159LA)	✓ (Use HM-168LWP)		
IC-F3022T/S, IC-F4022T/S	✓ (Use with BC-171)	✓ (Use with BC-121N or BC-197)			✓ (Use HM-158L)	✓ (Use HM-159L)			
IC-F3002, IC-F4002		✓ (Use with BC-197)	✓ (Use with BC-192)		✓ (Use HM-158L)	✓ (Use HM-159L)			
IC-F4029SDR	✓ (Use with BC-171)	✓ (Use with BC-121N or BC-197)			✓ (Use HM-158L)	✓ (Use HM-159L)			
IC-F27SR		✓ (Use with BC-197)	✓ (Use with BC-192)		✓ (Use HM-158L)	✓ (Use HM-159L)			

\*2 BC-123S/BC-145S/BC-147SA for 120V AC. SE for 230V AC. SV for 240V AC. BC-206SE for 230V AC.

MODEL NAME	SPEAKER-MICROPHONES		EARPHONE-MICROPHONES		HEADSETS			VOX/PTT CASE	PLUG ADAPTER CABLE
	HM-171GP IP54 GPS	HM-184 IP67	HM-153L/LA	HM-166L/LA	HS-94 Earhook type with boom microphone	HS-95 Behind-the-head type	HS-97 Throat microphone type	VS-1L/SC	OPC-2004
IC-F3262DT/DS, IC-F4262DT/DS									
IC-F3162DT/DS, IC-F4162DT/DS		✓							
IC-F3102D, IC-F4102D	✓								✓
IC-F51V, IC-F61V					✓ (Use with VS-1SC)	✓ (Use with VS-1SC)	✓ (Use with VS-1SC)	✓ (Use with VS-1SC)	
IC-F51, IC-F61 ATEX									
IC-F3032S, IC-F4032S			✓ (Use HM-153LA)	✓ (Use HM-166LA)	✓ (Use with VS-1L)	✓ (Use with VS-1L)	✓ (Use with VS-1L)	✓ (Use VS-1L)	
IC-F3022T/S, IC-F4022T/S			✓ (Use HM-153L)	✓ (Use HM-166L)	✓ (Use with VS-1L)	✓ (Use with VS-1L)	✓ (Use with VS-1L)	✓ (Use VS-1L)	
IC-F3002, IC-F4002					✓ (Use with OPC-2004)	✓ (Use with OPC-2004)	✓ (Use with OPC-2004)		✓
IC-F4029SDR			✓ (Use HM-153L)	✓ (Use HM-166L)	✓ (Use with VS-1L)	✓ (Use with VS-1L)	✓ (Use with VS-1L)	✓ (Use VS-1L)	
IC-F27SR					✓ (Use with OPC-2004)	✓ (Use with OPC-2004)	✓ (Use with OPC-2004)		✓

MODEL NAME	EARPHONES		EARPHONE ADAPTER	ACC ADAPTER	BELT CLIPS		LEATHER BELT HANGERS		CHARGER BRACKET
	SP-13	SP-27 Tube earphone	AD-52	AD-118 Allows you to use 6-pin Hirose plug accessories	MB-86 MB-93 Swivel type	MB-94 MB-94R MB-98 MB-124 Alligator type	MB-96N	MB-96F	MB-130
IC-F3262DT/DS, IC-F4262DT/DS									
IC-F3162DT/DS, IC-F4162DT/DS	✓ (Use with AD-52)	✓ (Use with AD-52)	✓		✓ (Use MB-93)	✓ (Use MB-94/R)	✓	✓	✓ (Use with BC-160)
IC-F3102D, IC-F4102D		✓				✓ (Use MB-124)			✓ (Use with BC-191, BC-192 or BC-193)
IC-F51V, IC-F61V					✓ (Use MB-86)	✓ (Use MB-98)	✓	✓	✓ (Use with BC-190)
IC-F51, IC-F61 ATEX					✓ (Use MB-86)	✓ (Use MB-98)			✓ (Use with BC-190)
IC-F3032S, IC-F4032S	✓	✓			✓ (Use MB-93)	✓ (Use MB-94/R)	✓	✓	✓ (Use with BC-160)
IC-F3022T/S, IC-F4022T/S	✓	✓			✓ (Use MB-93)	✓ (Use MB-94/R)	✓	✓	✓ (Use with BC-160)
IC-F3002, IC-F4002		✓				✓ (Use MB-124)			✓ (Use with BC-191, BC-192 or BC-193)
IC-F4029SDR	✓	✓			✓ (Use MB-93)	✓ (Use MB-94/R)	✓	✓	✓ (Use with BC-160)
IC-F27SR		✓				✓ (Use MB-124)			✓ (Use with BC-191, BC-192 or BC-193)