


K30 Quick Start Guide

Frequency: 2.402-2.480GHz - Power: 100mW



Installation

- Turn the screws to loose the clip;
- Open the inner lining of the helmet and insert the clip to the proper position and then fasten the screw;
- Push the Bluetooth onto the slot of the clip;
- Paste the velcro tapes into the helmet;
- Paste the earphone onto the velcro tapes;
- Insert the earphone plug to the Bluetooth.

Basic operations

Power On 	Power Off
Volume up 	Volume down
Reset the pairings (Under the power off status) 	Activate the voice command

Battery level checking

Check on phone 	Listen the voice reminder (Under the power off status)
---------------------------	--

Phone/MP3/GPS pairing

Under the power off status

--	--

Phone call operations

Answer a call 	Reject a call
End a call 	Redial the last number
Switching the audio from the device to the phone and viceversa 	
Turn On/off auto answer function (Under the power off status) 	

Music control

Play/Pause 	Next song
Previous song 	Music/FM switching

FM operation

Play/Turn Off FM 	Next channel
Previous channel 	Play/pause

Pairing between two units

A 		B
Under the Power off Status 1. A and B 2. A or B		

Bluetooth intercom operation

Two-Rider intercom 	Start/End intercom A or B
-------------------------------	-------------------------------------

Music sharing

Music sharing
Tips: This operation is possible only if the two devices are paired, and both of them should not be paired with any other K30 Lokui
End of sharing
Tips: This operation is possible only if the two devices are paired, and both of them should not be paired with any other K30 Lokui

For information about the warranty visit www.lokui.eu

LOKUI®
www.lokui.eu

K30 Quick Start Guide

Frequenza: 2.402-2.480GHz - Potenza: 100mW




Installazione


- Svitare le viti per allentare la clip della clamp.
- Inserire la clip della clamp tra la parete del casco e la sua imbottitura ed avvitare le viti per fissare il supporto.
- Fissare K30 sul supporto di fissaggio tramite l'apposito aggancio.
- Fissare il velcro all'interno del casco in corrispondenza delle vostre orecchie.
- Applicare gli altoparlanti sui velcro.
- Collegare gli altoparlanti al dispositivo tramite l'apposita presa.

Per iniziare


Accensione




Spegnimento



Volume su




Volume giù



Cancellare gli abbinamenti
(A dispositivo spento)




Attivare il comando vocale




Livello batteria

Avviso sul telefono






Ascolta il messaggio vocale
(A dispositivo spento)




Abbinamento con Telefono/MP3/GPS

A dispositivo spento




Modalità telefono


Rispondere ad una chiamata




Rifiutare una chiamata



Terminare una chiamata



Richiamare l'ultimo numero



Commutazione audio dall'interfono al telefono e viceversa



Attivare/disattivare la risposta automatica
(A dispositivo spento)



Musica

Play/Pausa



Canzone successiva



Canzone precedente



Commutazione Musica/radio FM



Radio FM


Riprodurre/spiegere la radio FM




Stazione successiva



Stazione precedente



Play/pausa



Abbinare due dispositivi



A dispositivo spento



A e B




A o B

Modalità intercom

Intercom moto a moto




Aprire/chiedere l'intercom



A o B

Condivisione musica




Condivisione musica



Nota: questa modalità è possibile solo quando i dispositivi sono abbinati tra di loro e con nessun altro interfono.

Interrompere la condivisione della musica



Nota: questa modalità è possibile solo quando i dispositivi sono abbinati tra di loro e con nessun altro interfono.

Per informazioni sulla garanzia visitate il sito www.lokui.eu

LOKUI®
www.lokui.eu