## SECTION 4 OPTIONAL PRODUCTS INSTALLATION



CAUTION! Optional unit installation should be done at an authorized Icom dealer or distributer.

## UT-133A

## Before the installation:


Prepare 2 sponges that comes with the IC-A120/IC-A120E.

Sponge


Sponge (Thick)

(Thin) (Th

- 1) Turn OFF the transceiver and disconect the DC power cable from the power supply.
- 2) Remove the top cover.




3) Remove the protect sheet from the Thin sponge, and then apply it to the PCB.




(Continued on the right above.)

4) Remove the protect sheet from the thick sponge, and then apply it to the UT-133A.



5) Attach the UT-133A to the connector on the PCB.



6) Attach the top cover.

