

Mounting instruction

AIRCELL® 7

N-Angle-Connector / Art. Nr.: 7399



1



Cut off cable tail right-angled.

2



Move the nut, clamping ring and rubber washer over the cable tail. Hint: With a bit of Vaseline the rubber washer can be moved easily over the cable sheath.

3



Remove 18 mm of the outer sheath with a knife.

4



Bend copper braid upwards right-angled. Insert contact sleeve between copper foil and braid until stop. Cut off protruding braid. Move the rubber seal to the front, up to the contact sleeve.

5




Mark out and remove the copper foil with a knife. Short the dielectric to a length of 10 mm.

6



The prepared cable tail has to be inserted into the housing until stop. Tighten the clamping nut finger tight with two open-ended spanners 16 mm. A small split should remain visible between clamping nut and connector housing. Then the inner conductor has to be soldered to the center contact.

7



Screw the closure cap firmly.

8

